


# Motor Movement Troubleshooting Chart


## Default Setup



This chart will walk you through the process to determine if the issue is with the Controller, motor, or motor harness.

If the issue is with the X or Z axis, swap between the Z and X axes instead of the Y axes

## Test 1 Swap Motor Harness at Controller



## Test 2 Default Harness Connection & Swapped Motors

